

# Storefront Installation Instructions - EOA

---

## GENERAL PRE-INSTALLATION NOTE

DO NOT UNLOCK the door until the unit is completely installed. The locked door will help aid in keeping the door / frame square during the installation process. Unlocking the door prior to completion of the installation may result in operation problems of the door.

KEYS, ANCHORS, FASTENERS & INSTRUCTIONS for this door are located in the box included in the crate.

This pre-assembled door has been prepared for an EXISTING OPENING APPLICATION. The frame has been prepared with “existing opening anchors.”

## INSTALLATION STEPS

1. After uncrating the door, position the unit into the existing opening. Shimming will be required to steady the unit as the installation progresses.
2. **PLUMB AND SQUARE DOOR UNIT.** Check the gap between the top of the door panel and header. There **MUST** be an even reveal.
3. The frame has been prepared with “existing opening anchors”. Secure each anchor with the fasteners provided. After all the fasteners have been installed, cover the preps with the vinyl caps that have been provided. Throughout this process, the unit **MUST REMAIN PLUMB & SQUARE.**
4. Remove fastener holding door leaf shut and check for proper operation.
5. Anchor threshold to floor with the anchors provided. Caulk or grout under the threshold.
6. Caulk or grout around the perimeter of the frame to prevent air / water infiltration.
7. Closer arm to be positioned 90 degrees from door leaf for proper operation.