

Installation Instructions – Vinyl Window with Subframe

Note: Windows with a steel subframe system have a “universal” jamb trim that allows the window to fall at any location along the wall panel.

1. It is recommended that the installation take place prior to the wall panels.
2. Stand the window in the location desired.
3. Secure both sides of the base through the tow holes on the base clips with the masonry anchors provided.
4. Raise the adjustable clip at the top of both subjambbs to the bottom of the girt. Plumb the window and attach these clips to the girt and subjambbs.
5. When sheeting, cut the panels as needed round the window. Make the cuts as close as possible to the window perimeter.
6. Run a continuous bead of sealant to form a watertight seal.
7. Field apply the finished snap-on trim on both window jambs

